



61993 CUSTOM FILL and **62003 WATERBORNE CUSTOM FILL** are premium aerosol blanks designed specifically for use with the **70701 CUSTOM FILL MACHINE**. This machine fills color into aerosols quickly, easily and with NO CLEAN UP!

61993 CUSTOM FILL

Use to fill solvent paints such as urethane basecoat, single stage, acrylic & alkyd enamels and acrylic lacquers.

62003 WATERBORNE CUSTOM FILL

Use to fill automotive waterborne basecoat and other waterborne coatings. Do not use in conjunction with solvent based paints.

70701 CUSTOM FILL MACHINE

- Remove cap and tip from aerosol blank and separate the disc from the top of the cap.
- Place disk into the machine, covering the piston. Run your finger around the edge to ensure proper alignment on the piston. The machine will not work until the disc is in place.
- Place cap into fill cylinder and lock in by twisting the cap. Ensure the cap is seated properly by pressing in the center of the cap.
- Attach the fill cylinder and cap to the aerosol blank.
- Pour paint into the cap. Do not fill past indicator line. Maximum fill is 90g.
- Insert can/cylinder unit into the machine by lining up the fill cylinder with the slots in the machine.
- Spin the pedestal counter-clockwise raising it up until it lightly touches the can. The pedestal should not be raised tight to the can.
- Close the safety door on the machine to start the filling process. The fill will complete in 10-15 seconds.
- Remove the can/cylinder assembly from the machine and separate the cylinder from the can. Remove the cap, which now holds a small amount of paint, by pressing the fill cylinder tabs, onto the work surface.
- Gently twist the spray tip onto the can.
- Shake for 1 minute and spray.



SEM PRODUCTS, INC. • Rock Hill, SC 29730 • 800-831-1122 • www.semproducts.com