


FlyTies Company



DIRECTIONS FOR USE

Note: Required tool that is not included – Hammer

TAKE INVENTORY

Qty. Description

- 3 ea. Hub, machined aluminum w/forged steel eyebolt
- 9 ea. Stakes, die-cast steel, 3/8" x 14", hex head, machined
- 1 ea. Removal tool
- 3 ea. Ropes, 3/8" x 12 ft.
- 1 ea. Tote bag, canvas, black, printed w/company information
- 1 ea. Instruction sheet

DIRECTIONS

1. Place one aluminum Hub on the ground directly under tie point of the wing with metal eyelet pointing up.
2. Insert one 3/8" x 14" stake into one of the three holes and drive into the ground using a hammer. **Important: Drive stake completely into the ground one at a time.** This will reduce binding and it will be easier to remove when you leave. The stake is fully inserted when the flair tabs on the stake touch the Hub. Repeat this step for the remaining stakes.
3. After your FlyTie unit is installed in the ground, secure wings and tail using ropes provided. Attach one end to the metal eyelet and the other to the wing hook, then secure with appropriate knot of your choice.

Removal

4. Using removal tool provided. Slip the opening under the hex head of the stake.
5. Remove stake by using a pulling and twisting motion until stake is removed straight out from the ground. Repeat this step for remaining stakes.

Note: In the event of extreme pulling force exerted on the FlyTie assembly during use, the stakes may bind slightly in the hub. If this happens, simply step down on the hub with your foot to release the tension. Then remove the stakes normally. (refer back to step 4 and 5).

Note:

Although extensive steps have been taken to make the FlyTies as safe and as easy to use as possible, common sense must be exercised in their use. FlyTies will not work in extremely soft, mushy soils. They have been tested in many different environments and have proved to perform well in most conditions. However, FlyTies cannot be responsible for any damage caused by misuse or carelessness.

Always make sure your FlyTies leave when your plane leaves so they will not cause damage to mowers, people, other planes, etc.

One-year money back guarantee

FlyTies are guaranteed for any defects that are due to faulty material or workmanship for a one-year period from the original date of purchase. If the product should become defective within the warranty period, we will elect to repair it or replace it free of charge.

This warranty does not include damage to the product resulting from misuse. There are no obligations or liabilities on the part of FlyTies Company for consequential damages arising out of or in connection with the use or performance of this product or other indirect damages with respect to loss of revenues or physical damage.

Rev. K	Date: July 10, 2014
Flyties Co.	Los Gatos, CA 408-966-4365 www.flyties.com