



C.R.S. D9QR836X

427 HILLCREST WAY • EMERALD HILLS • REDWOOD CITY, CALIFORNIA 94062 ■ (650) 369-1188 • Fax (650) 369-9988

Model 811C

CONTINUING AIRWORTHINESS

The model 811C requires a battery exchange every five years. The 811C uses a CR2032 coin cell lithium battery. Remove the single screw on back of unit to remove case. Lift up on right hand side of the battery to lift it out of the holder. With positive up, place new battery in holder left hand side first then push down into place. Replace the case with connector opening lined up and fasten with the single screw.

