


SYMBOL	REVISION	DRAWN	APPRVD



NOTES:

1. USE VAC2-4 FOR 4 CYLINDER ENGINES
USE VAC2-6 FOR 6 CYLINDER ENGINES
2. STANDARD LYCOMING DRIVE GEAR AND THRUST WASHER ARE USED
IN THE VAC2, NOT INCLUDED WITH THE VAC2
3. LUBRICATE GEAR SHAFT AND THRUST WASHER BEFORE
INSTALLING IN VAC2 CASTING

ITEM	-1 PART NO.		DESCRIPTION	
	UNLESS OTHERWISE SPECIFIED		B & C Specialty Products P.O. Box B, Newton, Kansas 67114	
DIMENSIONS ARE IN INCHES TOLERANCES ARE: DECIMAL 0.XX = ±0.03 DECIMAL 0.XXX = ±0.005 ANGLES = ±0.5 DEGREES			TITLE VAC2 CONNECTION DIAGRAM	
ENGINEER	NAME TH	DATE 9/4/02	DRAWING NO. BC704, 6SS	REVISION
DRAWN	TH	9/4/02	DATE	
CHECKED				
PROJECT			SCALE FULL	JOB NO. PAGE 1 OF 1