

PMA PRODUCTS REPLACEMENT PARTS

Oem	Description	Oem Part No.	Spruce Part No.	
Piper Cont'd	Switch, Landing Gear	67411-007	05-07438	.
	Switch, Landing Gear	67411-008	05-07439	.
	Switch, Landing Gear	67411-020	05-07441	.
	Switch, Landing Gear	67411-021	05-07442	.
	Down Limit Switch	95232-000	05-10891	.
	Bushing, Teflon	69790-000	05-07443	.
	Plate, Cowl	69791-000	05-07444	.
	Fitting, Swivel	70371-002	05-07446	.
	Stud Swivel	70371-003	05-07448	.
	Gasket, Fuel Bowl	751-871	05-07451	.
	Bushing, Torque Link	77780-005	05-07452	.
	Strut, Alternator Brace	78483-000	05-07453	.
	Bumper, Nose Gear	79072-000	05-07454	.
	Roller, Flap	86102-104	05-07457	.
	Roller, Flap	86102-105	05-07458	.
	Roller, Flap	86102-106	05-07459	.
	Bulkhead, Spinner	87325-010	05-07461	.
	Roller, Seat	87332-002	05-07462	.
	Bushing, Aileron Hinge	95061-108	05-07469	.
	Bushing, Nose Gear	95061-133	05-07471	.
	Hinge, tab	95864-002	05-07472	.
	Hinge, tab	95866-002	05-07473	.
	Barrel, Trim	96596-002	05-07474	.
Pratt & Whitney	Fuel Transfer Tube	3011155	05-07312	.
	Fuel Transfer Tube	3020030	05-07314	.
	Gasket, Fuel Nozzle	3029566	05-07316	.
	Gasket, Fuel Nozzle	3029678	05-07317	.
	Retainer Plate	3103345-01	05-07321	.
	Diaphragm	3103346-01	05-07322	.
	Diaphragm	3103347-01	05-07323	.
	Shim, Prop Shaft	3110998-01	05-07324	.
	Gasket	3118962-01	05-07326	.
	Gasket, Fuel Nozzle	Ms9371-16	05-07497	.
Raytheon/Beech	Seat Foot	100-530448-5	05-07239	.
	Seat Foot	100-530448-7	05-07242	.
	Bushing, Nose Gear	100-820017-1	05-07243	.
	Bushing, Landing Gear	101-810014-1	05-07244	.
	Bushing	101-810014-3	05-07246	.
	Bushing, M. Torque Link In Gear	101-810024-3	05-07252	.
	Torque Link Bushing	101-810024-5	05-07253	.
	Pin, Torque Link	101-810025-1	05-07254	.
	Bolt	101-810090-1	05-07257	.
	Bolt	101-810090-3	05-07258	.
	Bolt, Main Gear Drag Brace	101-810145-1	05-07261	.
	Bolt, Main Gear Drag Brace	101-810146-1	05-07262	.
	Door Closure Roller	105739x-yn1437	05-07263	.
	Bushing, N. Torque Link Ctr	105740x-ya0630	05-07264	.
	Bushing	105740x-yd0160	05-07267	.

Oem	Description	Oem Part No.	Spruce Part No.	
Raytheon/Beech Cont'd	Bushing	105740x-yk0563	05-07269	.
	Bushing	105740x-yn0520	05-07271	.
	Bushing, N. Torque Link Center	105740x-yn0625	05-07272	.
	Bushing, Main Drag Link Center	114-810038-1	05-07277	.
	Bushing, Main Drag Link In Gear	114-810042-1	05-07279	.
	Bushing, Main Drag Link In Gear	114-810049-3	05-07281	.
	Bushing, Nose Attach Lug	114-820113-1	05-07282	.
	Steering Roller	114-820062-1	05-07283	.
	Bushing	115-610019	05-07284	.
	Bushing, Main Gear	115-810064-1	05-07286	.
	Bushing	115-810066-3	05-07287	.
	Thrust Washer	115-810074	05-07288	.
	Switch, Stall	151	05-07294	.
	Fuel Cap Seal	457-98	05-07363	.
	Bushing, Torque Link	45-815013	05-07364	.
	Washer	50-105000-3	05-07382	.
	Wiper Blade (refill Only)	50-384082-1	05-07383	.
	Bushing	50-524476-1	05-07384	.
	Bushing	50-524476-3	05-07386	.
	Seat Foot	50-534436-5	05-07387	.
	Bushing, Upper Torque Link	50-810034	05-07388	.
	Main Strut Upper Bearing	50-810326	05-07389	.
	Pin	50-810343-5	05-07391	.
	Pin	50-810343-7	05-07392	.
	Switch, Mic	601-4300	05-07394	.
	Bushing, Ns Torque Link Center	90-810019-1	05-07466	.
	Bushing, Drag Link	90-820010-1	05-07467	.
	Bolt, Nose Gear	90-820011-1	05-07468	.
	Mic Switch	99-340253-1	05-07476	.
	Bushing, Torque Link	99-810060-1	05-07477	.
	Bushing	99-810064-1	05-07478	.
	Bushing	99-810064-3	05-07479	.
	Bushing, Main Drag Link Center	99-810066-1	05-07481	.
	Bearing, Nose Gear	99-820099	05-07482	.
	Yoke	A3025	05-07483	.
	Carbon Block	A3026	05-07484	.
	Carbon Block Assembly	A3044	05-07486	.
	Seal, Drain Valve	Cca1269	05-07494	.
	Seal, Drain Valve	Cca1319	05-07496	.
Saab	Bearing	Air130986	05-07488	.
	Bearing	Air130988	05-07489	.
Various	Filter / Gasket	Various	05-07338	.

AP