

MCFARLANE PARTS

AP

Model No.	Part No.	Description	Price
OMS24462-4	05-17336	McFarlane MS24462-4 Bearing, Needle	.
MC35-815109	05-27433	MC35-815109 Cable, Main Gear Up Lock	.
MC70371-00	05-27004	Fitting Assembly, Swivel	.
1111	05-06467	Stabilizer Jack Screw Actuator	.
CCH-KT-2	05-18513	McFarlane Cch-KT-2 Cessna Carb. Heat Repair Kits	.
CCH-KT-9	05-18678	McFarlane Cch-KT-9 Cessna Carb. Heat Repair Kits	.
MCS1230-17	05-04762	Carb Heat Cntl MCS1230-17	.
MCS1230-19	05-04763	Carb Heat Cntl MCS1230-19	.
MCS1230-10	05-04761	Carb Heat Cntl MCS1230-10	.
MC0411090-22CH	05-04756	Carb Heat Control C0411090-22Ch	.
MC565-548-041	05-00993	MC565-548-041 Mixture Control	.
MCS1104-3	05-17168	McFarlane MCS1104-3 Rod End, 3/16 Bore, 10-32 Internal Thread, Grease	.
MCS1106-3	05-17519	McFarlane MCS1106-3 Rod End, 3/16 Bore, 1/4-28 Internal Thread, Grease	.
A0750161-KIT	05-28998	A0750161-Kit Clamp Kit	.
FLP-KT-2U	05-19778	McFarlane Flp-KT-2U Flap Roller Upgrade Kit	.
FLP-KT-1U	05-20084	McFarlane Flp-KT-1U Flap Roller Upgrade Kit	.
FLP-KT-9U	01-01345	Flp-KT-9U Flap Roller Upgrade Kit	.
MC0523557-1	05-00283	Fuel Transmitter AS0523557-1	.
FQT-KT-2	05-04110	Fuel Quantity Transmitter Kit	.
MC0726110-1	05-00284	MC0726110-1 Fuel Transmitter	.
MCS1588-1	05-00285	MCS1588-1 Fuel Transmitter Gasket	.
MC0426517-1	05-00282	AS0426517-1 Fuel Transmitter	.
FQT-KT-1	05-04109	Fuel Quantity Transmitter Kit	.
MCS35010R10	05-00287-5	MCS35010R10 Transmitter Seal / Screw (Pack Of 5)	.
FQTP-KT-2	05-04875	Transmitter Kit Fqtp-KT-2	.
FQT-KT-3	05-12944	Fuel Quantity Transmitter Kit Fqt-KT-3	.
MCS1588-2	05-00286	MCS1588-2 Fuel Transmitter Gasket	.
MC0411257	05-04558	Universal Joint MC0411257	.
UJC-KT-1	05-22942	McFarlane Ujc-KT-1 Universal Joint Kit, Cessna	.
EBC-KT-5	05-04580	Elevator Bushing Kit Ebc-KT-5	.
MC0532104K	05-17008	McFarlane MC0532104K Bushing, Elevator Or Rudder Hinge	.
RBC-KT-6	05-04574	Rudder Bushing Kit Rbc-KT-6	.
RBC-KT-7	05-04575	Rudder Bushing Kit Rbc-KT-7	.
990	05-04869	Cessna Elev/Rudder Hng Bearing	.
MC0511243-4	05-00362	MC0511243-4 Seat Rail	.
MC0710658-2	05-00375	MC0710658-2 Seat Rail	.
MC0511243-5	05-00363	MC0511243-5 Seat Rail Outboard Left Hand	.
SEAT-KT-1	05-00425	McFarlane Seat Roller Kit 1 Articulating Seat FAA-PMA - SEAT-KT-1	.
SEAT-KT-2	05-00427	McFarlane Seat Roller Kit 2 Standard Seat FAA-PMA - SEAT-KT-2	.
MC2414002-2	05-00415	MC2414002-2 Seat Rail In Left Hand Out Right Hand	.
MC2414002-1	05-00414	MC2414002-1 Seat Rail Out Left Hand In Right Hand	.
MC0511243-6	05-00364	MC0511243-6 Seat Rail Outboard Right Hand	.
MC0410235-6	05-00344	MC0410235-6 Seat Rail	.
MC0511240-5	05-00355	MC0511240-5 Seat Rail	.
MC0511240-2	05-00352	MC0511240-2 Seat Rail	.
MC0511240-6	05-00356	MC0511240-6 Seat Rail	.

Model No.	Part No.	Description	Price
GAUGE SR1	05-04428	Seat Rail Wear Gauge SR1	.
SEAT STOP KIT 3	05-00582	Cessna Seat Stop Kit 3	.
MC0511240-11	05-00338	MC0511240-11 Seat Rail	.
MC0511293-3	05-00367	MC0511293-3 Seat Rail	.
MC0511000-15	05-00332	MC0511000-15 Seat Rail	.
MC0511293-2	05-00366	MC0511293-2 Seat Rail	.
MC0710618-6	05-00374	MC0710618-6 Seat Rail	.
MC0511240-3	05-00353	MC0511240-3 Seat Rail	.
SEAT-KT-3	05-00428	McFarlane Seat Roller Kit 3 Early & 150-152 FAA-PMA - SEAT-KT-3	.
MC0410219-1	05-00327	MC0410219-1 Seat Rail	.
MC0511293-1	05-00365	MC0511293-1 Seat Rail	.
MC1243426-2	05-22403	McFarlane Link Assembly Torque Upper	.
TL-SHIM-KT-1	05-15394	Torque Link Shim Kit	.
MCSK172-2	05-29067	McFarlane MCSK172-2 Seal Kit Nose Strut Cessna	.
180-185	05-27048	Tail Cone Angle Kit 180-185	.
MC565-580-038	05-00991	MC565-580-038 Prop Control	.
MC1260074-1	05-27269	McFarlane MC1260074-1 Trim Tab Actuator Assembly New Upright	.
MC62701-047	05-18454	McFarlane MC62701-047 Cable, Stabilator Trim, Aft	.
MC0510105-362	05-13306	MC0510105-362 Aileron Cable	.
MC0510105-364	05-13307	MC0510105-364 Aileron Cable	.
MC0750143-1	05-02361	Intake Heat Shield Deflector	.
MC0400311-119K	05-18438	McFarlane MC0400311-119K Fuel Vent Line Kit, Left Hand-Std	.
MC0756010-11	05-04424	Fuel Strainer Plunger MC0756010-11	.
FS-KT-1	05-01705	Fuel Strainer Gskt Kit Fs-KT-1	.
FS-KT-3	05-04426	Fuel Strnr Rebuild Kit Fs-KT-3	.
MC0756011-1	05-00281	AS0756011-1 Fuel Screen Standpipe	.
MC0756008-1	05-01704	Fuel Bowl MC0756008-1	.
FS-KT-5	05-04112	McFarlane Fs-KT-5 Fuel Strainer Assembly With Drain Cable	.
FS-KT-2	05-04425	Fuel Bowl Kit Fs-KT-2	.
FS-KT-4	05-04111	Fuel Strainer Kit	.
MC0756005-2	05-07238	Fuel Strainer Top Assembly	.
MC753-205	05-06826	Gasket Lower Seal MC753-205	.
MC751-898	05-06828	Gasket Lower Seal MC751-898	.
FSP-KT-1	05-06821	Fuel Gasket Kit Piper Fsp-KT-1	.
MC0426013-1	05-16653	McFarlane MC0426013-1 Gasket, Fuel Filler Neck	.
MC0523531	05-16755	McFarlane MC0523531 Gasket, Fuel Tank Adapter	.
MC0426013-2	05-16445	McFarlane MC0426013-2 Gasket, Fuel Filler Neck	.
MC0523532	05-16621	McFarlane MC0523532 Gasket, Fuel Tank Adapter	.
FSO-KT-17	05-17494	McFarlane Fso-KT-17 Repair Kit, Fuel Valve	.
FSO-KT-1	05-17932	McFarlane Fso-KT-1 Repair Kit, Fuel Valve	.
FSO-KT-13	05-17641	McFarlane Fso-KT-13 Repair Kit, Fuel Valve	.
FSO-KT-11	05-18122	McFarlane Fso-KT-11 Repair Kit, Fuel Valve	.
FSO-KT-16	05-17503	McFarlane Fso-KT-16 Repair Kit, Fuel Valve	.
SPOTFACE KIT	05-04429	Spotface Kit	.
MC0713070-28	05-18323	McFarlane MC0713070-28 Cable Assembly, Park Brake	.
MC62701-104	05-18160	McFarlane MC62701-104 Cable, Stabilator Trim, Fwd, Left Hand And Right Hand	.

VISIT WWW.AIRCRAFTSPRUCE.COM FOR A COMPLETE PARTS LIST.