

WHELEN STROBES

STROBE SYSTEM PARTS

Model No.	Description	Part No.	Price
A402R	Red Optic Lens	11-03254	.
A402W	White Optic Lens	11-03271	.
A402R/W	Split Red/White Optic Lens	11-03248	.
A406	Flash Tube Assembly	11-03687	.
A409	Clamp Ring Assembly	11-03688	.
A414A, HDH, CF	HDH,CF Power Supply	11-03632	.
A417-1	Interconnecting Cable	11-03658	.
A421-1	Warning Decal	11-03691	.
A425	Tail Strobe Lens Retainer	11-03692	.
A426	Wingtip Strobe Lens Retainer	11-03233	.
A427	Flash Tube Assembly	11-03219	.
A427-M	Flash Tube Assembly with Molex Connector	11-03272	.
A427-4	Rubber Pad Spacer	11-03693	.
A428	Wingtip Strobe Lens	11-03236	.
A428-C	Wingtip Strobe Radio Shielded Lens	11-03694	.
A428-D	Wingtip Strobe Radio Shielded Lens plus A426 Retainer Assembly	11-03290	.
A469A	Strobe Tube Assembly	11-03242	.
A430	Tail Strobe Head Assembly	11-03696	.
A435	Flash Tube Assembly	11-03697	.
A440	WRM-65 Mounting Adapter, for HR,DF & SA,DF	11-03699	.
A441	AMP Connector and 3 Pins	11-03211	.
A442	AMP Connector and 3 Sockets	11-03212	.
M441	Molex Connector and 3 Pins for Piper Installation	11-04215	.
M442	Molex Connector and 3 Sockets for Piper Installation	11-04216	.
A444	AMP Connector and 2 Pins	11-03700	.
M444	Molex Connector and 2 Pins for Piper Installation	11-04217	.
A446	AMP Connector and 2 Sockets	11-03702	.
A450	Strobe Head Assembly	11-03280	.
A455	Gasket	11-03703	.
A457A	Tail Light Lens for A500 and A555	11-03227	.
A457A-D	Radio Shielded Tail Light Lens Assembly for A500	11-03704	.
A466A-1	Radio Shielded Lens	11-03708	.
A467	Gasket for A470	11-03709	.
A469B	Flash Tube Assembly	11-03225	.

Model No.	Description	Part No.	Price
A470-D	Radio Shielded Remote Strobe Head Assembly, Specify Color	11-03291	.
A470-A-D-S	Strobe Head Assembly, Shielded Red/White	11-04976	.
A470-D-R-SU	Radio Shielded Remote Strobe	11-03714	.
A490 TC CF	14V Power Supply	11-02661	.
A500-V-D-M-14	Radio Shielded Tail Position & Strobe Light Head Assembly Vertical Mount with Molex Connector	11-03722	.
A508-14	Halogen Lamp for A500, A555, A600	11-03216	.
A508-28	Halogen Lamp for A500, A555, A600	11-03208	.
A509	Lamp Shield for A500 and A555	11-03727	.
A510-28	Lamp Assembly for A500 & A555	11-03266	.
A50828	Lamp for A500, A555, & A600	11-03208	.
A605	Base Plate Assembly	11-03733	.
A606	Retainer	11-03260	.
A610	Flash Tube Assembly	11-03213	.
A610-M	Flash Tube Assembly	11-03734	.
A612	Magnifying Lens	11-03222	.
A612-D	Radio Shielded Lens Retainer Assembly	11-03735	.
A615	Lens for A600 Tail Light	11-03230	.
A616	Gasket for A600 Tail Light	11-03261	.
A625	Tail Strobe Head	11-03228	.
A625-D	Radio Shielded Tail Strobe Head Assembly	11-03659	.
A626	Retainer Lens	11-03229	.
A626-D	Radio Shielded Lens Retainer Assembly	11-03736	.
A627	Flash Tube Assembly	11-03263	.
A628	Retainer Lens	11-03737	.
A629	Gasket	11-03660	.
A650	Wingtip Strobe Head Assembly	11-03215	.