

OWNERS MANUALS – PIM

Part No.	Decription	Price	Part No.	Decription	Price	Part No.	Decription	Price
14-03117	C172K Air Force T-41a Flight Handbook	.	14-00765	Cessna 172G & Sky-hawk 1966	.	14-00453	Cessna 310G 1962	.
14-03089	C180 1953	.	14-00766	Cessna 172H & Sky-hawk 1967	.	14-01372	Cessna 310H 1963	.
14-03093	C180 1957	.	14-00767	Cessna 172I & Sky-hawk 1968	.	14-01373	Cessna 310J 1964	.
14-03095	C180 1959	.	14-00768	Cessna 172K & Sky-hawk 1969	.	14-01374	Cessna 310J 1965	.
14-03096	C180 1960	.	14-00769	Cessna 172K & Sky-hawk 1970	.	14-01375	Cessna 310K 1966	.
14-03097	C180 1963	.	14-00770	Cessna 172L & Sky-hawk 1971	.	14-01376	Cessna 310L 1967	.
14-03113	C180 1963-68 Floatplane Supplement	.	14-00771	Cessna 172L & Sky-hawk 1972	.	14-01377	Cessna 310N 1968	.
14-03098	C180 1964	.	14-00772	Cessna 172M & Sky-hawk 1973	.	14-01378	Cessna 310P 1969	.
14-03099	C180 1965	.	14-00773	Cessna 172M & Sky-hawk 1974	.	14-01379	Cessna 310Q 1970-72	.
14-03101	C180 1967	.	14-00774	Cessna 172M & Sky-hawk 1975	.	14-01380	Cessna 310Q 1973	.
14-03102	C180 1968	.	17-00124	Cessna 172R 180 Hp Pro Pilot Checklist	.	14-01381	Cessna 310Q 1974	.
14-03103	C180 1969	.	17-00126	Cessna 172R-im Aus with Nav III Glass Panel (Green Star)	.	14-01382	Cessna 310R 1975	.
14-03112	C180 1969-72 Floatplane Supplement	.	14-00800	Cessna 175 & Skylark 1959	.	14-01400	Cessna 320 1962	.
14-03104	C180 1970	.	14-00684	Cessna 175 1958	.	14-01401	Cessna 320A 1963	.
14-03105	C180 1971-72	.	14-00801	Cessna 175A 1960	.	14-01402	Cessna 320B 1964	.
14-03106	C180 1973	.	14-00802	Cessna 175B 1961	.	14-01403	Cessna 320C 1965	.
14-03107	C180 1974	.	14-00803	Cessna 175C 1962	.	14-01404	Cessna 320D 1966	.
14-03108	C180 1975	.	14-00804	Cessna 177 & Cardinal 1968	.	14-01405	Cessna 320E Skynight 1967	.
14-03110	C180D 1961	.	14-00805	Cessna 177A & Cardinal 1969	.	14-01406	Cessna 320F Skynight 1968	.
14-03109	C180E 1962	.	14-00811	Cessna 177B & Cardinal 1975	.	14-01422	Cessna 337 1965	.
14-03111	C180J 1975 Floatplane Supplement	.	14-00806	Cessna 177B 1970	.	14-01421	Cessna 337A 1966	.
14-03076	C185 Skywagon 1961	.	14-00807	Cessna 177B 1971	.	14-01407	Cessna 337B 1967	.
14-03072	C185 Skywagon 1961-65 Float Supplement	.	14-00808	Cessna 177B 1972	.	14-01408	Cessna 337C 1968	.
14-03077	C185 Skywagon 1964	.	14-00809	Cessna 177B 1973	.	14-01409	Cessna 337D Super Skymaster 1969	.
14-03078	C185 Skywagon 1965	.	14-00810	Cessna 177B 1974	.	14-01410	Cessna 337E 1970	.
14-03073	C185 Skywagon 1966 Float Supplement	.	14-00776	Cessna 182 & Skylane 1957-58	.	14-01411	Cessna 337F 1971	.
14-03080	C185 Skywagon 1967	.	14-00775	Cessna 182 1956	.	14-01412	Cessna 337F 1972	.
14-03074	C185 Skywagon 1967-68 Float Supplement	.	17-00133	Cessna 182 Tim-bus w/integrated Autopilot	.	14-01413	Cessna 337G 1974	.
14-03081	C185 Skywagon 1968	.	14-00777	Cessna 182B Skylane 1959	.	14-01414	Cessna 337G Skymaster 1973	.
14-03082	C185 Skywagon 1969	.	14-00778	Cessna 182C Skylane 1960	.	14-01415	Cessna 337G Skymaster 1975	.
14-03075	C185 Skywagon 1969-72 Float Supplement	.	14-00779	Cessna 182D Skylane 1961	.	14-01442	Cessna 340 1972	.
14-03083	C185 Skywagon 1970	.	14-00780	Cessna 182E Skylane 1962	.	14-01443	Cessna 340 1973	.
14-03071	C185 Skywagon Float Supplement	.	14-00781	Cessna 182F & Skylane 1963	.	14-01444	Cessna 340 1974	.
14-03114	C185A 1962	.	14-00782	Cessna 182G & Skylane 1964	.	14-01445	Cessna 340 1975	.
14-03115	C185B 1963	.	14-00783	Cessna 182H & Skylane 1965	.	14-01454	Cessna 401 1967-1968	.
14-00662	Cessna 120 & 140 1946-1948	.	14-00784	Cessna 182J & Skylane 1966	.	14-01455	Cessna 401A 1969	.
14-00661	Cessna 140A 1949-51	.	14-00785	Cessna 182K & Skylane 1967	.	14-01456	Cessna 401B 1970-1972	.
14-00263	Cessna 150 1959-60	.	14-00786	Cessna 182L & Skylane 1968	.	14-01461	Cessna 402 1967-1968	.
14-00552	Cessna 150A 1961	.	14-00787	Cessna 182M & Skylane 1969	.	14-01462	Cessna 402A 1969	.
14-00264	Cessna 150B 1962	.	14-00788	Cessna 182N & Skylane 1970	.	14-01463	Cessna 402B 1970-1972	.
14-00265	Cessna 150C 1963	.	14-00789	Cessna 182N & Skylane 1971	.	14-01464	Cessna 402B 1973	.
14-00266	Cessna 150D 1964	.	14-00790	Cessna 182P & Skylane 1972	.	14-01465	Cessna 402B 1974	.
14-00267	Cessna 150E 1965	.	14-00791	Cessna 182P & Skylane 1973	.	14-01468	Cessna 402B Businessliner 1975	.
14-00540	Cessna 150F 1966	.	14-00792	Cessna 182P & Skylane 1974	.	14-01481	Cessna 414 1970-72	.
14-00541	Cessna 150G 1967	.	14-00793	Cessna 182P & Skylane 1975	.	14-01482	Cessna 414 1973	.
14-00542	Cessna 150H 1968	.	17-00130	Cessna 182S 1997 - 2000 (Purple Star)	.	14-01483	Cessna 414 1974	.
14-00543	Cessna 150J 1969	.	17-00131	Cessna 182T 2001 & Up (Yellow Dot)	.	14-01484	Cessna 414 1975	.
14-00544	Cessna 150K 1970	.	14-01304	Cessna 188, 188a 1966-67	.	14-01494	Cessna 421 Golden Eagle, Exec Comm 1968	.
14-00545	Cessna 150L 1971	.	14-01305	Cessna 188, 188a 1968-69	.	14-01495	Cessna 421A 1969	.
14-00546	Cessna 150L 1972	.	14-01306	Cessna 188A, A188B 1970-71	.	14-01496	Cessna 421B 1970-1971	.
14-00547	Cessna 150L 1973	.	14-01307	Cessna 188B & A188B AG Wagon 1972-73	.	14-01497	Cessna 421B 1974	.
14-00548	Cessna 150L 1974	.	14-01308	Cessna 188B & A188B AG Wagon 1974	.	14-01498	Cessna 421B 1975	.
14-00549	Cessna 150M 1975	.	14-01309	Cessna 188B & A188B AG Wagon 1975	.	14-01499	Cessna 421B Golden Eagle 1972	.
17-00151	Cessna 152 Aerobat 1979	.	14-01323	Cessna 190, 195, 195A, 195B 1946-1953	.	14-01500	Cessna 421B Golden Eagle 1973	.
14-00663	Cessna 170 1948	.	14-01324	Cessna 205 1963	.	14-00004	Cessna A150K Aerobat 1970	.
14-00664	Cessna 170A 1949-51	.	14-01325	Cessna 205A 1964	.	14-00005	Cessna A150L Aerobat 1971	.
14-00665	Cessna 170B 1952-55	.	14-01326	Cessna 207 Skywagon 1969	.	14-00655	Cessna A150L Aerobat 1972	.
14-00666	Cessna 170B 1956	.	14-01327	Cessna 207 Skywagon 1970	.	14-00656	Cessna A150L Aerobat 1973	.
14-00668	Cessna 172 & Sky-hawk 1957-58	.	14-01328	Cessna 207 Skywagon 1971-73	.	14-00657	Cessna A150L Aerobat 1974	.
14-00669	Cessna 172 & Sky-hawk 1959	.	14-01329	Cessna 207 Skywagon 1974	.	14-00658	Cessna A150M Aerobat 1975	.
14-00696	Cessna 172 & Sky-hawk 1963	.	14-01330	Cessna 207 Skywagon 1975	.	14-03086	Cessna A185F 1973 Skywagon	.
14-00667	Cessna 172 1956	.	14-00458	Cessna 310 1955-1956	.	14-03087	Cessna A185F 1974 Skywagon	.
17-00167	Cessna 172 RG 1985	.	14-03358	Cessna T210N 1979	.	14-03088	Cessna A185F 1975 Skywagon	.
17-00129	Cessna 172 Sim-bus W/integrated Autopilot	.	14-00457	Cessna 310B 1957-58	.	14-03085	Cessna A185F Skywagon	.
14-00694	Cessna 172B & Sky-hawk 1961	.	14-00456	Cessna 310C 1959	.	14-03118	Cessna FR172J Reims Rocket Flight Manual	.
14-00695	Cessna 172C & Sky-hawk 1962	.	14-00455	Cessna 310D 1960	.	14-01423	Cessna P337G 1974	.
14-00763	Cessna 172E & Sky-hawk 1964	.	14-00454	Cessna 310F 1961	.	14-01424	Cessna P337G 1975	.
14-00764	Cessna 172F & Sky-hawk 1965	.				14-01425	Cessna P337G Skymaster 1973	.