

## **DroMight™ Oxygen Tube Retention Clips For Headsets with 9.75mm Flat Wishbone Frames**

For a color version of the instructions below, please visit <https://www.terrestrialimaging.com/products/oxygen-tube-retention-clips-for-9-75mm-flat-frame-pilot-headsets>

**Please read all directions prior to installation and first use.**

Thank you for purchasing the DroMight™ Oxygen Tube Retention Clips for your aviation headset. These oxygen tube retention clips solve a common frustration in the cockpit – keeping your oxygen cannula tubes securely routed without crushing them between your ears and the headset ear cups. Purpose-built for pilots who fly with supplemental oxygen, these clips snap directly onto the ear cup's flat 9.75mm wishbone frame without the need for tools, adhesives, or modifications. The end result is an easy to use, comfortable and unobstructed fit. Once installed, the oxygen retention clips can remain on your headsets for life and will not interfere with normal use, even when flying without oxygen. Of course, you can easily remove the retention clips anytime you choose and store them away for reinstallation at a later date.

Follow the steps below to **install** the oxygen retention clips on your 9.75mm flat wishbone frames.

**Step 1:** Remove the clips from the packaging and prepare to install them on either the left or right side of the headset.



# **DroMight™**

Oxygen Tube Retention Clips

**Step 2:** Place the oxygen retention clip over the headset frame so that the clips opening faces up as show in the picture below.



**Step 3:** Gently stretch the clip over the flat wishbone frame so that the clip captures the flat wishbone frame completely (as show in the picture below).



# DroMight™

Oxygen Tube Retention Clips

**Step 4:** Repeat this process for each clip. Your kit includes six total oxygen tube retention clips (three for the left ear cup and three for the right ear cup).



**Step 5:** If there is a wire running down the center of the flat ear cup wishbone frame, run the wire through the wire channel built into the clip as show in the picture below.



# DroMight™

Oxygen Tube Retention Clips

**Step 6:** When properly installed, your clips will resemble the picture below. Spread the clips out evenly throughout the frame. Repeat the above steps for the other ear cup.



Follow the steps below to **remove** the oxygen retention clips from your headset.

**Step 1:** Gently stretch the clip over the frame using your fingers (tools are not required) as shown in the picture below.



**Step 2:** Store the clips in a safe place for reinstallation at a future date.



## Kit Contents

DroMight™ Oxygen Tube Retention Clips

- 6 x oxygen tube retention clips
- Clips can be used interchangeably on either side of the headset
- Made from flexible nylon material
- Be careful not to bend the clips excessively



## Warranty

Manufacturer warrants that the DroMight™ Oxygen Retention Clips conform to Manufacturer's specifications and are free from defects in material and workmanship. Unless otherwise specified by manufacturer in writing, this warranty extends for **two years from the date of original purchase**. All warranties apply only to the original Purchaser unless otherwise agreed by Seller and manufacturer in writing. Manufacturer's sole obligation and Purchaser's exclusive remedy for any justified claim under this warranty shall be limited to one of the following, at

Manufacturer's sole discretion: (a) repair or replacement of the Product or (b) a credit for the price paid by the original Purchaser of the Product. This express warranty does not apply to, and no warranty remedy will be given for, Product issues resulting from (a) accident, acts of nature, improper installation, improper assembly, unreasonable or improper use, lack of proper maintenance, unauthorized repairs or modifications, abuse, normal wear, or other causes not directly arising from defects in materials or workmanship; (b) use of this product in any way that is deemed illegal; (c) use of this product for military purposes; (d) any Product damaged by the failure of the owner to use, maintain, or store the Product as specified in any applicable instructions and/or warnings provided by Seller or the manufacturer. EXCEPT FOR LIMITED WARRANTY SET FORTH ABOVE, SELLER MAKES NO WARRANTY WHATSOEVER, EXPRESS OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR AGAINST INFRINGEMENT. IN THE EVENT WARRANTIES EXIST AT LAW THAT MAY NOT BE DISCLAIMED, PURCHASER AGREES THAT SUCH WARRANTIES SHALL BE LIMITED IN DURATION TO THE TWO YEAR WARRANTY PERIOD AND TO THE REPLACEMENT VALUE OF THE PRODUCT. CUSTOMER IS RESPONSIBLE FOR RETURN SHIPPING COSTS FOR ANY WARRANTY CLAIMS.