



51 Winthrop Road

Chester, Connecticut 06412-0684

Phone: (860) 526-9504 Fax: (860) 526-2009 Internet: www.whelen.com

Sales/Service e-mail: aviation@whelen.com

Installation Guide:

Model 7199400
P/N:01-0771994-00
LED Anti-Collision Light Assembly

TSO-C96a CLASS III; APPROVED



The conditions and tests required for TSO approval of this article are minimum performance standards. Those installing this article either on or within a specific type or class of aircraft must determine that the aircraft installation conditions are within the TSO standards which include any accepted integrated non-TSO functions. TSO articles and any accepted integrated non-TSO function(s) must have separate approval for installation in an aircraft. The article may be installed only according to 14 CFR part 43 or the applicable airworthiness requirements.

## **OPERATING INSTRUCTIONS:**

 Operational Voltage:
 28 VDC


 (Operation from 21-32 VDC)

 Average Input Current:
 0.32 Amps

 Pulse:
 1.8 Amps

 Flashrate:
 45± 4 Comet Bursts per minute

 Weight:
 0.46 lbs. (ref.)



**EQUIPMENT LIMITATIONS:** An approved Anti-Collision lighting system consists of two lights, one located on each wingtip. The assembly should be mounted as far outboard on the aircraft as practical. The assembly must be mounted parallel to the vertical and horizontal centerlines of the aircraft to project the patterns properly. Certain types of installations may require additional testing.

**CONTINUED AIRWORTHINESS:** Model 71994 anticollision light assembly is designed with 18 LEDs. If any one LED fails, the unit must be repaired or replaced. **Note:** To reduce eye strain use an optical filter such as dark glasses or a blue covering dome during LED inspection.

Inspect the lens and replace if there is excessive scratching, pitting, discoloration or cracking.

For additional lens maintenance detail, see SAE ARP5637.

**INSTALLATION PROCEDURES:** The following information provides guidelines for the installation of the Whelen LED anti-collision light. Please refer to the OEM manual for your aircraft for specific removal and installation instructions.

- Using the mounting detail information provided, prepare the aircraft for means to secure the light assembly.
- 2. Connect the light inputs according to the chart shown. Connect the power lead to an appropriately sized breaker. Connections to be in accordance with FAA approved methods. NOTE: SYNC is a low power input control signal that causes the lights to flash at the same time, If Synchronization is not necessary, the connection may be left open.
- Carefully remove and discard the 2 screws from the retainer. CAUTION: Do not touch the LED with either fingers or sharp objects as this could soil and/or damage the LED and affect the optical performance of the light.
- Using the appropriate hardware install the unit to the aircraft. Ensure that all leads are clear of any obstructions and secured as required. NOTE: Proper orientation is achieved with the drain hole down.
- 5. Place the light switches in the ON position and verify proper operation of the Whelen lights.
- Check all avionics systems for interference from this installation.
- A flight check should be performed by a properly certified pilot.
- When necessary, waterproof the light base to the aircraft. Apply single part slicone (RTV) or equivalent around any open area where water could get in. Do not cover the drain hole.
- Update aircraft records, complete Form 337 and obtain FAA field approval for installation, as required.

