


Thank you for purchasing the Six Pack Aero GMU 11 Wingtip Bracket.

This wingtip bracket is designed and fabricated from 2024-T3 aluminum to meet the material specifications outlined by the Garmin G5 and GMU-11 Magnetometer installation instructions in accordance with the applicable Supplemental Type Certificate. Installation of the bracket must be done in accordance with AC43.13-2b Chapter 1 and 2, and AC43.13-1B Chapter 4. This bracket is not FAA PMA'd.

To set the angle of the wingtip bracket:

1. Attach the bracket to the last rib of the wing.
2. Gently adjust the bracket angle so that the GMU-11 Magnetometer is level per the Garmin installation manual.
3. Once the angle is set, locate the holes on the left and right sides of the bracket. (Detail A)
4. Drill a hole through and install rivets in accordance with AC43.13-1B to set the angle of the bracket.

GMU-11 BRACKET DETAIL



GMU-11 BRACKET GENERAL LOCATION EXAMPLE